

## DMX Channel Values

Channel	Value	Function
1	000 ⇔ 031	<b>Mode</b> Laser off
	032 ⇔ 067	Clockwise scanning
	068 ⇔ 103	Counter-clockwise scanning
	104 ⇔ 139	Beam shake
	140 ⇔ 175	Strobing
	176 ⇔ 201	Single beam
	202 ⇔ 240	Auto mode
	241 ⇔ 255	Sound-active mode
2	000 ⇔ 255	<b>Speed Control</b> Slow to fast